


## PROFESSIONAL MODELS





	Wide/Narrow area Flip lens	PIR	Microwave
IR-D-P1E	✓	✓	
IR-D-P2E	✓	✓	✓ (10,525 GHz)
IR-D-P2E-UK	✓	✓	✓ (10,587 GHz)



# CONTENTS

<b>Before installation</b>	
- Manufacturer's statement	Page 2
- Parts identification	3
<b>1 Installation</b>	
Disassemble 3	
	
Wall mount without bracket 4	
Wall mount with bracket 5	
Ceiling mount with bracket 6	
Assemble and connect 7	
<b>2 Settings</b>	
Wide/Narrow setting 9	
Jumper pin settings 9	
PEU settings 10	
<b>3 Checking 11</b>	
<b>Others</b>	
- Specifications	12
- Dimensions	13
- Detection area	13
- Angle adjustment	14
with bracket IR-D-CW-G2	
- Compliance	15






# Before installation

## - Manufacturer's statement






Symbol	Meaning	Symbol	Meaning
 <b>Warning</b>	Failure to follow the instructions provided with this indication and improper handling may cause death or serious injury.		Check mark indicates recommendation.
 <b>Caution</b>	Failure to follow the instructions provided with this indication and improper handling may cause injury and/or property damage.		No sign indicates prohibition.
		<b>NOTE</b>	Special attention is required to the section of this symbol.




### **Warning**



### **Caution**




## - Parts identifications




## Option

IR-D-CW-G2 \*  
Bracket for wall/ceiling mount



Mounting screw x 2  
Joint screw x 3  
Fixing screw x 2

PEU \*\*  
Plug-in EOL Unit



\* Not certified to EN 50131-2-2:2017 /  
EN 50131-2-4:2020 and INCERT.


\*\* Not evaluated by UL

## 1


## Installation

## 1-1. Disassemble


1 Unlock the cover



2 Open the cover



3 Remove the main unit




# 1-2. Wall mount without bracket

## 1 Wire through the base


Wiring knockouts

For Wall/ Corner mount  
Hidden wiring:

For Wall/ Corner mount  
Surface wiring  
: Upper  
: Lower




How to break the knockouts




A. Surface wiring


A-1. Upper



A-2. Lower




B. Hidden wiring



## 2 Mount the base

Mounting holes




For Wall mount

For Corner mount  
Select 2 of the 3 on each side.


NOTE

Mounting screws are not included.  
Φ 3 mm screws are recommended.

a. Wall mount





b. Corner mount





## 1-3. Wall mount with bracket


### 1 Wire and mount on the wall



#### NOTE

See page 4 for how to break the knockouts.

### 2 Join the base on the bracket




#### NOTE

Adjust the detection direction while jointing.

Confirming with a walk test is required.

--> Refer to "3-1. Walk test"

### 3 Fix the base with the fixing screws (optional)



The bracket is basically jointed using 3 holes and 3 joint screws. Also use 2 additional fixing screws if stronger support is required.


#### NOTE

2 fixing screws are required for the Grade 2 and higher grade installation.


# 1-4. Ceiling mount with bracket

How to change the bracket to the ceiling mounting


[1] Loosen the fixing screw.





[2] Rotate the body.



[3] Tighten the fixing screw.




1 Wire and mount on the ceiling



NOTE

See page 4 for how to break the knockouts.

2 Join the base on the bracket




NOTE

Adjust the detection direction while jointing.

Confirming with a walk test is required.

--> Refer to "3-1. Walk test"

3 Fix the base with the fixing screws (optional)




The bracket is basically jointed using 3 holes and 3 joint screws. Also use 2 additional fixing screws if stronger support is required.

NOTE


2 fixing screws are required for the Grade 2 and higher grade installation.

## 1-5. Assemble and connect

### 1 Attach the main unit to the base



### 2 Connect wires to the terminal



#### Power cable length

The power cable should be limited to the following length.

#### IR-D-P1E

WIRE GAUGE	12 V DC	14 V DC
AWG 22 (0.33 mm <sup>2</sup> )	520 m (1,710 ft.)	1,130 m (3, 718 ft.)
AWG 20 (0.52 mm <sup>2</sup> )	820 m (2,690 ft.)	1,790 m (5,870 ft.)
AWG 18 (0.83 mm <sup>2</sup> )	1,320 m (4,330 ft.)	2,850 m (9,350 ft.)


#### IR-D-P2E

WIRE GAUGE	12 V DC	14 V DC
AWG 22 (0.33 mm <sup>2</sup> )	410 m (1,350 ft.)	890 m (2,920 ft.)
AWG 20 (0.52 mm <sup>2</sup> )	650 m (2,130 ft.)	1,400 m (4,590 ft.)
AWG 18 (0.83 mm <sup>2</sup> )	1,030 m (3,380 ft.)	2,240 m (7,350 ft.)



## 2-1. Wide/Narrow setting

- 1 Set the Flip lens to "Wide" or "Narrow"


Go to 2-2 on  to skip 2-1 when using the default "Wide" setting.



**WIDE**  
Default



**NARROW**





## NOTE


Install the lens so that the letters on the cover and on the lens match your intention.

## How to remove the lens

Get over the rib, then pull up the lens.




If it is difficult to get over, use a flathead screwdriver.



## Caution

- Be careful not to damage the light path of the LED.
- Also, be careful not to allow the light path to pinch the wiring when closing the cover.




## Caution


- Be careful not to damage the lens with a screwdriver.

## How to install the lens

Push the lens firmly at 3 points in numerical order.



## 2 Set the jumper pin to "Wide" or "Narrow"




### ⚠ Caution

- The jumper pin must be "Narrow", when the lens is set to "Narrow".


### NOTE

- Default setting is "Wide".
- When "Narrow" is selected, MW detection will be disabled.

## 2-2. Jumper pin settings




### ③ Wide/Narrow




### ① LED

ON: LED is activated always.  
OFF: LED can be controlled through the Remote LED terminal.  
[Open; OFF 0 V; ON]




### ④ MW sensitivity [IR-D-P2E only]






### ② PIR sensitivity

H: High sensitivity  
M: Medium sensitivity  
L: Low sensitivity


Illustrations show the default position.



## 2-3. PEU settings




**NOTE**  
Align both triangle marks.




## 3-1. Walk test


1 Confirm that the LED pin is "ON", then close the cover.




2 Walk in the detection area to check the detecting performance via LED indication.



3 Return the LED pin to "OFF" after the walk test, if necessary.



4 Lock the cover



## NOTE

Conduct a walk test at least once a year.



## - Specifications

Model		IR-D-P1E	IR-D-P2E / UK
Installation			
Detection method		Passive infrared	Passive infrared and Microwave
Coverage		Wide: 15 m (50 ft.) 85°/ Narrow: 24 m (80 ft.) 5° ( No MW detection at "Narrow" setting )	
Detection zones		Wide: 78 zones/ Narrow: 18 zones	
Mounting height		2.0 to 3.0 m (6'7" to 9'8")	
Alarm period		2.0 ± 0.5 s	
Warm-up period		Approx. 60 s (LED blinks)	
LED indicator		Switchable ON/OFF Green: [1] Warm-up [2] Alarm	
Electrical			
Power input		9.5 to 16 V DC	
Current draw		8 mA (normal) 11 mA (max.) at 12 V DC	11 mA (normal) 14 mA (max.) at 12 V DC
Relay output	Alarm	N.C. 24 V DC 0.1 A max. (Resistive load)	
	Tamper	N.C. 24 V DC 0.1 A max. (Resistive load) (Open when the cover is removed.)	
Remote LED		Terminal: open = OFF 0 V = ON	
Environmental			
Operation temperature		-20°C to +50°C (-4°F to +122°F)	-20°C to +45°C (-4°F to +113°F)
Temperature compensation		Digital (SMDA)	
Environmental humidity		95% max.	
RF interference		No alarm 10 V/m	
Mechanical			
Dimension		H: 129.2 x W: 61.5 x D: 50.9 mm (H: 5.09" x W: 2.42" x D: 2.00")	
Weight		Approx. 95 g (3.35 oz) (with Bracket : Approx. 125 g (4.41 oz))	Approx. 110 g (3.88 oz) (with Bracket : Approx. 140 g (4.94 oz))
Mounting		Wall, Corner (Indoor) (with Bracket : Wall, Corner, Ceiling)	

- Specifications and designs are subject to change without prior notice.
- These units are designed to detect an intruder and activate an alarm control panel.  
Being only a part of a complete system, we cannot accept responsibility for any damages or other consequences resulting from an intrusion.




## - Dimensions




## - Detection area


Wide - Top view -




Narrow - Top view -



Wide - Side view -







Narrow - Side view -



### NOTE



- The \* 2.4 m dotted line indicates the recommended mounting height.
- When "Narrow" is selected at the jumper pin, MW detection will be stopped.

- Angle adjustment with bracket IR-D-CW-G2



NOTE

\* If the detector cover does not reach the ceiling, it can be swung up to +5°.



## - Compliance

### RE Directive 2014/53/EU

- IR-D-P2E and IR-D-P2E-UK comply with RE Directive 2014/53/EU.
- Microwave emission Frequency and Power
  - IR-D-P2E: 10.525 GHz 15.78 mW e.i.r.p
  - IR-D-P2E-UK: 10.587 GHz 8.93 mW e.i.r.p
- The following list indicates the areas of intended use of the equipment and any known restrictions.  
For countries not included in this list, please consult the responsible Spectrum Management Agency.
  - 10.525 GHz: Belgium, Denmark, Finland, Germany, Greece, Italy, Luxembourg, The Netherlands, Spain, Sweden, Iceland, Norway, Switzerland
  - 10.587 GHz: Belgium, France, Germany, Ireland, Luxembourg, The Netherlands, United Kingdom
  - 9.425 GHz: Austria, Czechia, Estonia, Germany, Slovakia, Turkey, Russia
- IR-D-P2E and IR-D-P2E-UK also comply with EU radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

### UK Radio Equipment Regulations 2017

- IR-D-P2E-UK also comply with UK radiation exposure limits set forth for an uncontrolled environment.  
This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.
- The radio equipment type IR-D-P2E-UK is in compliance with Radio Equipment Regulations 2017.

### FCC/IC

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
- This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
  - (1) This device may not cause interference.
  - (2) This device must accept any interference, including interference that may cause undesired operation of the device

- EN 50131-1 Grades and Environmental Class; Security Grade 2, Environmental Class II  
Applied Standards; EN 50131-2-2 (IR-D-P1E), EN 50131-2-4 (IR-D-P2E and IR-D-P2E-UK)  
Tested and certified by Telefication
- Iarm klass 2, miljö klass II, SSF 1014
- PD6662:2017



INNERRANGE.COM

Global Headquarters  
Inner Range Australia  
1 Millennium Court, Knoxfield, Victoria, 3180, Australia

Inner Range Middle East  
Plot No S20141, PO Box 16854  
Jebel Ali Free Zone - South, Dubai, UAE

Inner Range United States  
2301 Patriot Blvd  
Glenview, IL 60026

Inner Range Canada  
200 Foster Crescent Mississauga,  
Ontario, Canada L5R-3Y5

Inner Range United Kingdom  
Units 10-11 Theal Lakes Business Park  
Moulden Way, Reading, Berkshire RG74GB

Inner Range India  
National Sales Office 95 Brigade Road,  
Bangalore, 560 025 India