
$P \wedge R \wedge D \cap X^{\mathsf{T}}$







End-User Management Software

Puts You in Control

NEware offers management, control and convenience right from your computer, with graphical representation of your system and point-and-click ease of use. The NEware software is designed to make security and access control simple for the Digiplex EVO security system owner.

Access Control Rights

Restrict entrance to your premises to only authorized individuals and assign rights that specify which areas each person can access. Pre-set up to 32 schedules, such as a day, evening, holiday or weekend shift, and then simply assign each cardholder to a specific schedule.

Customized Reports

Create customized reports to track the activities of a specific individual, a high-traffic zone or a restricted area. Filter your reports by date, by time, by event or by other criteria and then save or print it out. Save reports in popular formats, such as .pdf, .txt, .csv, .html, .xls, .rtf or for a higher level of security, save reports as .qrp files which can only be opened using NEware.

NEware from Anywhere

Monitor you system from anywhere in the world. When your system includes an IP Internet Module or a PCS Series Module, you can remotely access your system from any web-connected computer that has NEware installed, giving you all of the features you have when connecting on-site. Wherever you are, you are in control.

System Requirements

- Compatible with Windows® 2000/XP, Vista (32 or 64-bit)
- 256MB RAM (512 recommended)
- 150MB of available hard-disk space
- Pentium III 800 MHz or higher
- Super VGA Monitor (best viewed at 1024 x 768 resolution)

Managing Multiple Users

With NEware you can manage the user codes and access rights, of up to 999 people in your system. Create new users by entering a name and then specifying his or her access rights and security options. You can also copy and paste a user's options for an even faster solution. Either way, with NEware you have point and click control, without ever needing a keypad.

Monitor your System Live

Monitor all real-time events as they occur in your system. Should an alarm occur you will receive instant notification on your screen.

Control your System

Arm or disarm your system, lock or unlock doors bypass zones and control devices such as your lights, heating or garage door right from your computer.





Software Editions

| Features | Demo (DNEWARE-DM) | Security (NEW-SEC) | Security and Access Control (NEW-ACC) |
|--|----------------------|-----------------------|---------------------------------------|
| Create and delete users | Up to 5 users | Up to 999 users | Up to 999 users |
| Assign security options to users | 4 | 4 | 4 |
| View system events | Only sample events | 4 | 4 |
| Monitor and Control the system | Monitor only | No door control | 4 |
| Create and print reports | 4 | 4 | 4 |
| Set and assign access control options to users | 4 | - | 4 |