

IPECS EHS - LED INDICATIONS

LED Color	Description
White	indicates that the data transceiver is disconnected between the device and EHS Adaptor.
Red	indicates that the link is disconnected, or data communication is failed between device and EHS Base Set (such as Plantronics or Jabra). If you experience this problem, we suggest you turn Off the power of EHS Base and turn on again.
Green	indicates that the EHS Adaptor protocol type is set with KTS, or EHS Base Set is in standby mode or during a call.
Blue	indicates that the EHS Adaptor protocol type is set with SIP, or EHS Base Set is in standby mode or during a call.
Red ↔ Blue	EHSA is in mode to discover Sennheiser EHS.

SIP = 1000i SERIES PHONES
IPKTS = OLDER 9000 SERIES PHONES

